

Heavy Duty Floor Seal Fitting Instructions

STEP 1



Lay your seal out flat in a warm place overnight to let the rubber become more flexible.

Clean any dust from the floor and make sure it is totally dry.

Cut a notch to let the seal fit behind the frame and butt up against the bottom of the frame and the back of the door.

STEP 2



Close the door and slide the seal into place to meet the back of the door.

Open the door and mark both sides of the seal on the floor.

Remove the seal.

STEP 3



For the best seal, run a couple of lines of sealant between the lines and rub into the concrete as a primer then proceed as below

Lay lines of the sealant along the marked area.

Do not go too close to the line you have marked as it will squeeze out when you place the seal on it.

STEP 4



Put the seal into place and press down.

Close the door to check the seal is in the correct place.

Seal along the edges and where it meets the frame for a fully waterproof seal. If the ends tend to curl up weight them down to let them bond securely

Leave to set overnight before driving over it.